



Insert microSD card into Peartree2 unit, then Power-On.
It will bootup Android 2.2 in Japanese Language.



There may be previously setup ICONs.
Select the Language ICON by pressing your finger to the slight right of the ICON.
NOTE-1: PT2 calibration is offset, so that is why selecting to the slight right.
NOTE-2: If there are no ICON(s), then see below for selecting from scratch.




After selecting your desired Language, then please press the "Force close" button each time to finish. "Force close" is a false error message.

You can get back to MAIN MENU(s) by pressing the PT2 right side crucial tech h/w BUTTON.



If the ICONs on the PT2 are different(ie. have changed), then you can start from scratch.

To get a proper sub-menu to show up, you will have to PRESS your finger onto the LCD screen to eventually get a sub-menu shown below:



NOTE: You may have to play with pressing your finger at the MAIN MENU level to get it to work, including rebooting to get refreshed MAIN MENU(s).

Selecting these choices will create a Language ICON on the MAIN MENU for later easy usage.



NOTE: To roll a screen's selections, press your finger firmly, then swipe in the desired direction. If you do it not so firmly it will select at the point you put your finger.

After selecting ENGLISH (United States), you will have English menus for Peartree2 - Android 2.2 OS.